



LG Encore GT550 Battery Replacement

This guide will demonstrate to the user how to replace the battery.

Written By: Lindsey Harding



INTRODUCTION

We are going to demonstrate how to take replace the battery.

Step 1 — Battery



- Push the back cover off

Step 2



- Push the battery out by pushing from the end furthest from the camera.

Step 3



- Take the old battery out and install a new one.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-27 06:50:00 PM.